



1. Mark two screw holes at required location through mounting bracket (top and bottom)
2. Drill 7/32" hole and insert anchors
3. Secure mounting bracket using two fasteners
4. Position cover plate and robe hook over bracket and tighten set screw from the bottom using an allen wrench

