



1. Mark two screw holes for each of the mounting brackets at the required CC 18"/24"/30"
2. Drill 5/16" holes and insert anchors
3. Secure mounting brackets using two fasteners for each bracket
4. Position cover plate and towel bar over brackets and tighten set screws from the bottom of each bracket using an allen wrench

