



1. Mark two screw holes at required location through mounting bracket (top and bottom)
2. Drill 5/16" hole and insert anchors
3. Secure mounting bracket using two fasteners
4. Position tissue holder over bracket and tighten set screw from the bottom using an allen wrench

