



Hard Wired

1. Drill 7/8" hole
2. Install sub-mount plate using two fasteners
3. Pull wire from through sub-mount plate and wire to push button (ensure electrical breaker is off)
4. Insert push button onto cover plate and loosely tighten retainer ring
5. Thread on cover plate to sub-mounting plate and tighten set screw from the bottom using an allen wrench
6. Now tighten retainer nut by hand

