



1. Remove Cap on door stop
2. Place door stop into position and mark where hole is to be drilled
3. Drill 5/16" hole either a pilot hole if wooden floor or a hole big enough to house anchor (insert anchor) in concrete floor  
Be cautious not to drill into under floor heating systems
4. Place door stop over hole and secure with screw
5. Screw on cap should now be inserted

